


Mounting instructions for eccentric clamp module

Insert by pushing and turning



Clamping by swivelling

