

## Fine adjustment for workpiece stabiliser



#### Item description/product images



## **Description**

#### **Product description:**

The fine adjustment enables the distance between the workpiece and support table to be precisely set. If required, the fine adjustment can be used to set the workpiece stabiliser under tensile or compressive load.

#### **Material:**

Steel.

#### **Version:**

Adapter piece black oxidised. Half shells nitrided.

#### Note:

Only the fine adjuster K1187.25120150 is required for workpiece stabiliser system size 25.

When using fine adjustment on the workpiece stabiliser system size 50, the fine adjuster K1187.25120150 and the adapter K1187.50 (consisting of 2 adapter pieces and a grub screw) are required at the respective ends.

## **Drawing reference:**


1) DIN EN ISO 4762 M10 cap screw

# Fine adjustment for workpiece stabiliser




## **Drawings**

System size 25



Adapter for system size 50



## **Overview of items**

## Fine adjustment for workpiece stabiliser

Order No.	Item	Size	В	D	D1	D2	Н	L min.	L max.	L	L1	L2	SW
K1187.25120150	Fine Adjustment	25	44	25	M16x1,5	9	46	120	150	-	16	-	21
K1187.50	Adapter	50	-	39,7	M16x1,5	M27x2	-	-	-	38	34	35	36