


Mounting instructions for eccentric clamp module



Insert by pushing and turning



Clamping by swivelling

