



Installation instructions for levelling foot with hollow screw

Supplied with one hollow screw, one plate, one nut.


1. Place the levelling foot in the position intended for the machine.



2. Once the levelling foot and the machine are positioned correctly, drill a hole in the floor through the hollow screw.



3. Insert a stud or pin through the hollow screw into the floor and secure it (e.g. with glue).



4. The levelling foot and the machine are now fully secured (no visible holes in the floor).

